

NAME OF THE TERMINAL: ex - G&G INTERNATIONAL NV

LOCODE: BEWLB13127T030000236

OVERVIEW: Port facility consisting of one quay.

LOCATION: On the Zeekanaal Brussel – Schelde, an inland waterway, more specific a canal for sea-going vessels, south of Antwerp, Belgium.

Latitude: 51° 02' 39" N longitude: 004° 21' 42" E

CHARTS: BA Charts No. 120, 128 and 1874 and local chart.

BERTHING: Quay length 120 m.

MAX DRAFT¹: 5,8 m

OPERATOR: Waterwegen en Zeekanaal NV, Oostdijk 110, 2830 Willebroek, Belgium,
Tel: + 32 (0) 3 860 62 11, Fax: + 32 (0)3 860 63 05

USEFUL TELEPHONE NUMBERS AND VHF CHANNELS:

Zeesluis Wintam (lock)	Tel: + 32 (0) 3 860 6293 Fax: + 32 (0) 3 860 6306 SluisWintam@WenZ.be	Channel 10, 68
Centrale Zemst	VTS-Operatoren@WenZ.be	Channel 25
Harbour masters office	+ 32 (0) 3 860 6297	
RIS (River Information Services)	+ 32 (0) 9 253 94 71	

PILOTAGE & USE OF BOATMEN:

Pilotage and the engagement of licensed boatmen is compulsory on the Zeekanaal Brussel-Schelde. Exemptions are to be requested via the shipping agent.

Ordering of Pilot and boatman via <https://webapps.portofantwerp.com/secured/apicsloket/>

TUGS COMPULSARY IF:

Vessels with a LOA > 120 meter: 1 tug

Vessels with a beam > 17 meters and a bow thruster: 1 tug

Vessels with a beam > 17 meters, no bow thruster: 2 tugs

Vessels with a draft > 7 meters and no bow thruster: 2 tugs

Vessels with a draft > 7 meters and a bow thruster: 1 tug

Tugs are to be ordered via <https://webapps.portofantwerp.com/secured/apicsloket/>

¹ Max draft in Fresh water, without guarantee, to be checked with agents /operations

ISPS COMPLIANCE:

Zeesluis Wintam (lock) is an ISPS port facility (BEWTH – 0001).
Ship's ISPS arrival information is to be filled in via
<https://webapps.portofantwerp.com/secured/apicsloket/>

MAXIMUM SIZE:

- Zeesluis Wintam to Ruisbroek: max. LOA 180 m, max. beam 24 m, max. draft 8,80 m (depending on berth) and max air draft 48 m
- Ruisbroek to railway bridge Willebroek: max. LOA 140 m, max. beam is 24 m, max. draft 6,5 m (depending on berth) and max. air draft 48 m
- Railway bridge Willebroek to Brussel: max. LOA 140 m, max. beam 16,50 m, max. draft 5,80 m (depending on berth) and max. air draft 32 m

WATER DENSITY: 1.01

GENERAL INFORMATION CONCERNING DOCUMENTS:

Custom clearance:

Customs clearance of vessel effected upon passage Antwerp roads or whilst the vessel is at anchor, awaiting the suitable tide at Oosterweel Rede (Antwerp Roads) to reach Wintam lock at high tide.

The following forms are required for port clearance:

- 2 crew lists
- 1 ship's stores
- 1 bonded stores list
- 1 crew declaration
- 1 tonnage certificate.

Manifest:

The transport document that serves as a tally-sheet, gives a detailed summary of all bills of lading issued by the carrier (or its agent) for a particular vessel. The manifest lists its consignor, consignee, number, origin, destination, value, and other such information, primarily for use by the customs authorities.

APPROACHES for sea-going vessels:

Vlissingen and Antwerpen roads:

Deep draught vessels will, depending on the tide, have to anchor at Vlissingen Rede or Oosterweel awaiting the suitable tide window for Wintam approach.
The ship then has to proceed upstream on the incoming tide, arriving at Wintam lock at high tide. Wintam lock is located just West of the intersection of the river Rupel and the River Schelde. The lock is the river entrance from the river Schelde to the Zeekanaal Brussel-Schelde.

Wintam Lock:

Operational since 1997
Dimensions of the lock: length 250 m., width 25 m., depth 9,50 m.
Only standard or wooden fenders are allowed in the lock.

Zeekanaal Brussel-Schelde to berth:

Before arriving at the berth following bridges (and 1 lock) are to be passed:

1. Nijverheidsbrug (Puurs): no air draft limitation, maximum width: 50 m.
2. Boulevardbrug (Willebroek): no air draft limitation, maximum width: 54,00 m.
3. Ijzerenbrug (Railway bridge Willebroek): no air draft limitation, maximum width: 18,90 m.
4. Vredesbrug: maximum air draft: 32 m. maximum width: 35 m.

Berth:

The berth is a concrete wall quay. Ship's fenders are required.

Ships up to 150 m can swing in the turning basin in front of Waterwegen & Zeekanaal NV quay, about 800 m before arriving (downstream) the G&G International NV Quay.

CARGO GEAR:

No cargo gear available. Loading or unloading operation is done via mobile cranes or ship's own gear. Use of the RORO facility.

TERMINAL SAFETY:

The use of standard safety equipment is mandatory for all ship's crew members.

See also ship/shore check list and the ILO accident prevention on board ship and in port and the International Safety Code of Practice.

The C 134 Prevention of Accidents (Seafarers) Convention.

FRESH WATER:

To be arranged via shipping agent.

FUEL:

To be arranged via shipping agent. Delivery is possible by truck or barge.

WASTE DISPOSAL:

In accordance with the Directive 2000/59/EC on port reception facilities for ship-generated waste and cargo residues (see also objective Marpol 73/78, being the protection of the marine environment) and in accordance with the Flemish legislation, decree of 2nd of July 1981 concerning waste prevention and management, VLAREA, and the authorization given by OVAM to the zeesluis Wintam to operate as an approved waste collector, vessels can deliver shipgenerated waste restricted to Marpol annex V (i.e. domestic waste).

Each sea-going vessel bound for a port facility on the Zeekanaal Brussel-Schelde, calling at the zeesluis Wintam, must contribute to the cost for the collection and processing of ship-generated waste, irrespective of the actual use of the port reception facility.

Vessels bound for the port of Brussel have the possibility to deliver shipgenerated waste and cargo residues in Brussel.

SLOPS DISPOSAL:

To be arranged via shipping agent.

AUTHORITY:

WATERWEGEN EN ZEEKANAAL NV, Oostdijk 110, 2830 Willebroek, Belgium.

Tel: +32 (0) 3 860 6211. Email: info@WenZ.be